

## OPERATING and MAINTENANCE INSTRUCTIONS for H135WUA11 Series Hot Cabinet

### REPLACEMENT PARTS:

| DESCRIPTION              | 120 VOLT    | 208 VOLT    | 240 VOLT    |
|--------------------------|-------------|-------------|-------------|
| Hot Unit (135WUA11)      | PHU-747-071 | PHU-747-072 | PHU-747-073 |
| Hot Unit (135WSUA11)     | PHU-747-080 | PHU-747-081 | PHU-747-082 |
| Heater (Reservoir)       | 0811-285    | 0811-286    | 0811-287    |
| Pan (Reservoir)          | 1017-097    | 1017-097    | 1017-097    |
| Heater (Air)             | 0811-214    | 0811-250    | 0811-215    |
| Thermostat Kit           | 0848-062-K  | 0848-062-K  | 0848-062-K  |
| Thermometer Kit (Analog) | 5238-030-K  | 5238-030-K  | 5238-030-K  |
| Power Cord               | 0810-065-1  | 0810-039    | 0810-039    |
| Proof & Heat Lights      | 0766-093    | 0766-093-1  | 0766-093-1  |
| Power Light              | 0766-094    | 0766-095    | 0766-095    |
| Switch (Power)           | 0808-116    | 0808-116    | 0808-116    |
| Switch (Mode Selection)  | 0808-117    | 0808-117    | 0808-117    |
| Blower Kit               | 0769-180-K  | 0769-182-K  | 0769-182-K  |
| Drip Pan Kit             | 1017-058    | 1017-058    | 1017-058    |

