


Ovens	FL-2374-FL
Rev. 0 (8/14)	Page 1 of 1

QUICK START GUIDE for Cres Cor Fleming's Steakhouse Ovens



HOW TO START:

- 1. Push the lighted power switch to start the oven. This will initiate the oven in a "HOLD" mode.
- 2. The display will read "LOTPR" (low temperature) until the oven reaches 140°F. (60°C.).

NOTE: Wait one (1) hour after start up before loading the food for best results.

3. Plug probe into the probe jack on the face of the oven. (This unit comes with 2 probes: A 6" probe for Prime Rib and a 3" probe for other items. See Figure 1.)

TO SELECT A RECIPE:

- 1. Push the Recipe Button marked 1-6. Use the control knob to select Menu 1 for Prime Rib.
- 2. Once recipe is selected, push the Control Knob to confirm your selection.
- 3. Push the Start Button to initiate preheat for cooking. The display will read "PREHT" until the cabinet reaches the set temperature, then it will show "READY".
- 4. Load meat into oven and insert probe spike into the center of the meat.

NOTE: The probe lead should exit the top of the oven near the plug jack to prevent kinking.




FIGURE 1

- 5. Close the cabinet door.
- 6. Push the Start Button to begin the cooking cycle. The indicator light next to the Cook Button will illuminate, along with the Probe Button indicator light.
- 7. The oven will now cook the meat until the preselected probe temperature is reached. At that point, the oven will go into HOLD mode and the indicator light next to the Hold Button will illuminate.
- 8. Upon completion of the recommended hold time, disconnect the probe and remove the meat for processing.
- 9. Sanitize probe and lead and store for future use. You can now start a new recipe as illustrated in Step 1.

NOTE: To cancel program at any time, press and hold the Control Knob for 5 seconds. This will cancel the program and allow operator to change operations.